



Cold Lay Macadam is a ready to use, cost-effective tarmac that can be used to carry out repairs to asphalt areas needing reinstatement following site investigation work.

Cold Lay Tarmac is easy to use as no tools or specialist equipment is required.

Applications

- Reinstatement repairs

Typical Coverage

- One bag of Cold Lay Macadam will cover approximately 0.4 m² at 30mm when compacted
- Hardening time will depend on the degree of compaction and ambient temperature

Storage

- Always keep the bag sealed when not in use

Features

- Ready to use
- No specialist tools or equipment needed
- Suitable for base or wearing course

Usage Guide

- Ensure the area is dry and firm and clear of weeds and debris
- Use a spade or trowel to spread the Cold Lay Macadam to the required thickness
- Use a roller or heavy flat object for 'tamping' to achieve a good compaction
- Wet the roller or tamper frequently to stop the Macadam from sticking to the tool
- Dust a little dry sand over the Cold Lay after compaction to prevent picking up the tarmac as it sets
- When repairing deep holes (greater than 30mm) lay the Cold Lay Macadam in two stages and make sure to compact the first layer before adding the second layer